

The following procedure is to be used for installation in concrete, pavement, asphalt, and off-roadway applications

## PREPARATION

- + Excavate 6" deeper than the overall height of the enclosure and another 6" wider than the overall length and width.
- + Add 6" of crushed rock, gravel, or sand to the base of the hole.

## ENCLOSURE INSTALLATION

- + Place enclosure in hole so that the top of the unit is at grade level. Add or remove gravel base if necessary.

## BACKFILL

- + Add backfill and compact until 6" of space remains below the finish grade. It is recommended that for the last 6" a concrete collar is poured.

